

EM20-80 / TRX2020

Enable Scanner Beep



@SETUPE1
Enter Setup



@GRBENA1
**** On**



@SETUPE0
**** Exit Setup**

